

COMPONENTS, OPERATION & OPTIONS

Operation :

■ 3 possibilities for supplying power :

- > Existing hydraulic power unit + extended tube circuit dedicated to the furler;
- > Existing hydraulic power unit + Facnor control box + 5-meter flexible tube
- > Facnor micro hydraulic power box + Facnor control box + 5-meter flexible tube

Options :

■ 4-functions control box : control box driven by manual switch or remote controllers*

+ 2x 5-m flexible tubes

Specific functions :

Release – to reduce pressure and plug the connectors in
Disengage – to furl out at high speed (300 to 400 turns/min instead of 120 turns/min)

*receiver/radio remote control,

■ 4-function control box + micro power unit

■ integrated in-deck version (IDXH) :

Small dimensions.

- Standard furler including :
 - «stand-up» articulated toggle
 - swivel - fitted with a standard or a 2-to-1 top attachment
 - a protection cover.

