


## RELAY BOX / REMOTE CONTROL



■ **The Relay box** is a polarity inverting gear that is placed between the power supply (battery + circuit breaker) and the drive unit. It inverts the rotation direction and therefore enables to furl in or out. the foil sections turn at constant speed

■ **Waterproof circuit breaker** (delivered in the standard kit) : turns off the furling gear in case of overheating (due to a Genoa sheet not released for instance).