

**Internal turnbuckle option** fig. ④ : With the internal turnbuckle fitting, the turnbuckle can be positioned inside the drum and be easily adjusted. 5 models available

Internal turnbuckle option	LS 60	LS 70	LS 100	LS 130	LS 165	LS180	LS 200	LS290	LS330
	LX 60	LX 70	LX 100	LX 130	LX 165	LX 180	LX 200	LX290	LX330
<b>LS &amp; LX Internal turnbuckle fitting</b> ø inner dimension & lgth (mm)	ø 28 lgth 256		ø 34 lgth 279		ø 42 lgth 315		ø 50 lgth 432		ø 64 lgth 546
<b>RX Internal turnbuckle fitting</b> ø inner dimension & lgth (mm)	-	<b>RX 70</b>	<b>RX 100</b>	<b>RX 130</b>	<b>RX 165</b>	<b>RX 220</b>	<b>RX260</b>	<b>RX300</b>	-
		ø 28 lgth 256			ø 34 lgth 279		ø 42 lgth 315	ø 50 lgth 432	

